



Talon Simulations, LLC

279 Douglas Ave #1104
Altamonte Springs, FL 32714
Phone: (407) 440-1356 ext 2
www.talonsimulations.com

1. Unscrew 4x screws that mount the plastic housing but leave in place.
2. Remove the seat and detached wires that connect to Tactile Transducers with 17mm wrench.
3. Reference the image above. Unscrew the Control Box with Phillips head. Twist to 90 degrees and pull through the hole and place on top of plastic housing. Remove zip ties.
4. Using a 5mm allen key, unscrew the 8x M6 bolts that screw the Spider into the Universal Joint.
5. Undo the Velcro that is holding on the soft covering on the left and right rods and unscrew the two M8 bolts with 6mm allen key.
6. Lift entire upper section assembly off to the side
7. Lift up plastic housing and move to the side.
8. Perform the above instructions in reverse in order to re-assemble the system properly.